



INSTALLATION INSTRUCTIONS: IGNITION COVERS

Part #'s : IC-0001-B, IC0001-C

KIT INCLUDES: 1 ignition cover with adhesive tape

Do not attempt to fit parts to motorcycle unless properly trained. Incorrect fitment may result in injury or death.



1. Carefully remove red protective tape on back side of ignition cover.



2. Place the Brouhard ignition cover over your existing ignition cover.



3. Apply even pressure for approximately 30 seconds. Allow an hour for proper adhesion before riding.



4. ENJOY!

Thank you for purchasing a Brouhard designed product. Extreme care has gone into the design and production. Should you not be 100% satisfied or have any questions, please email us at brouharddesigns@yahoo.com